




EXTINDERE LOCUINTA PARTER  
FATADA LATERALA DREAPTA (EST) SC. 1 / 50



EXTINDERE LOCUINTA PARTER  
FATADA LATERALA STANGA (VEST) SC. 1 / 50



EXTINDERE LOCUINTA PARTER  
FATADA POSTERIOARA (NORD) SC. 1 / 50



EXTINDERE LOCUINTA PARTER  
FATADA PRINCIPALA (SPRE STRADA) SC. 1 / 50

